

FAQ10032 - Tiger Touch Non Pro BIOS Settings

Select **“Load Optimized Defaults”** and enter

Set **“Supervisor Password”** to **68340**

Set **“User Password”** to **68340**

Enter the **“Standard CMOS Features”** Menu

Set the correct **“Date and Time”**

Set **“Drive A”** to **[none]**

Set **“Halt on”** to **[All, But Keyboard]**

Enter the **“Advanced BIOS Features”** Menu

Set the **“First Boot Device”** to **[Hard Disk]**

Set the **“Second Boot Device”** to **[Disabled]**

Set the **“Third Boot Device”** to **[Disabled]**

Set **“Swap Floppy Drive”** to **[Disabled]**

Set **“Boot Up Floppy Seek”** to **[Disabled]**

Set **“Boot Up NumLock Status”** to **[Off]**

Enter the **“Advanced Chipset Settings”** Menu

Set the **“Onchip VGA Control”** to **[Auto]**

Set the **“LCD Type”** to **[7]**

Enter the **“Integrated Peripherals”** Menu, and

then enter the **“Onboard Device”** Menu.

Set the **“USB Keyboard Support”** to **[Enabled]**

Enter the **“Integrated Peripheral”** Menu, and

then enter the **“Super IO Device”** Menu.

Set the **“PWRON After PWR-Fail”** to **[Former-Sts]**

Press **Escape**, then **F10** to Save to CMOS and **Y** followed by **Enter**