

Avolites Ltd.

Engineering Change Notice

| | |
|-----------------------|---|
| Title | Borris 2 Xtal |
| ECN Number | ECN-0115 |
| Equipment | Desks with Borris 2 motherboard: Sapphire 2000 (pre SAP 2064), Azure (pre AZ 450), Pearl (Post PRL 786 and pre PRL 1251) |
| Author | Adam Proffitt |
| Drawing Number | |
| Date | 27 th Jan 2000 |

| | |
|-------------------------------|---|
| Reason for ECN | CPU crystal can intermittently touch capacitor legs and cause erratic desk operation. |
| Special Parts required | None |
| Special Tools required | None |

Work Required

Locate cylindrical Xtal (marked X10 on circuit board) next to MC68340 processor on Borris 2 motherboard.
Carefully lift the Xtal so that it stands away from the nearby capacitors (C100 and C101).

